Computer Networks Lab Task #4 Saad Ahmad 20P-0051

Task 1

First add 2 PCs and 1 switch and 1 server.

Then configure the PCs by assigning the IP address, subnet mask and DNS server IP like:

PC1:

```
IP = 192.168.1.3
Subnet mask = 255.255.255.0
DNS server = 192.168.1.2
```


PC2:

```
IP = 192.168.1.4
Subnet mask = 255.255.255.0
DNS server = 192.168.1.2
```

DNS Server:


```
IP = 192.168.1.2
Subnet mask = 255.255.255.0
DNS server = 192.168.1.2
```

Now go to the services tab of the DNS server and select DNS from the menu and then add the PCs record in it.



Remember to turn "on" the DNS service.

And now connect them all using the straight through cable.



Result:

```
C:\>ping PC2

Pinging 192.168.1.4 with 32 bytes of data:


Reply from 192.168.1.4: bytes=32 time<1ms TTL=128
Reply from 192.168.1.4: bytes=32 time<1ms TTL=128
Reply from 192.168.1.4: bytes=32 time=9ms TTL=128
Reply from 192.168.1.4: bytes=32 time=1ms TTL=128

Ping statistics for 192.168.1.4:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 0ms, Maximum = 9ms, Average = 2ms

C:\>
```

Task 2

First add 3 PCs and 1 switch and 1 router.



Then configure the Router using CLI

```
Router>
Router>enab
Router>enable
Router#conf
Router#configure ter
Router#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#interf
Router(config)#interface Gig
Router(config)#interface GigabitEthernet 0/0
Router(config-if)#ip address 192.168.1.1 255.255.255.0
Router(config-if)#exit
Router(config)#interface GigabitEthernet0/0
Router(config-if)#no shi
Router(config-if)#no shu
Router(config-if)#no shutdown
Router(config-if)#
```

Now we will configure DHCP server on the Router.

```
Router(config)#ip dhcp pool P1
Router(dhcp-config)#netwo
Router(dhcp-config)#network 192.168.1.1 255.255.255.0
Router(dhcp-config)#dns
Router(dhcp-config)#dns-server 192.168.1.10
Router(dhcp-config)#ec

^
% Invalid input detected at '^' marker.

Router(dhcp-config)#ec
Router(dhcp-config)#e
Router(dhcp-config)#exit
Router(config)#
```

And now connect them all using the straight through cable.

Now go to every PC and on their IP, configuration tabs, enable DHCP. Every PC should be able to obtain an IP address, default gateway and DNS server.

○ Static
192.168.1.3
255.255.255.0
192.168.1.1
192.168.1.10

Result:

```
C:\>ping PC2

Pinging 192.168.1.4 with 32 bytes of data:

Reply from 192.168.1.4: bytes=32 time<1ms TTL=128

Reply from 192.168.1.4: bytes=32 time<1ms TTL=128

Reply from 192.168.1.4: bytes=32 time=9ms TTL=128

Reply from 192.168.1.4: bytes=32 time=1ms TTL=128

Ping statistics for 192.168.1.4:

Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),


Approximate round trip times in milli-seconds:

Minimum = 0ms, Maximum = 9ms, Average = 2ms

C:\>
```

Task 3

First add 3 PCs and 1 switch and 1 server



Now we will configure the server so for that assign the IP to the server and DNS server

IP:

192.168.1.2

DNS:

192.168.1.10

Now go to the service tab and select the DHCP from the menu. Then proceed to define the DHCP network parameters as follows:

Pool name: serverPool

Default Gateway: 192.168.1.1

DNS Server: 192.168.1.10

Start IP Address: 192.168.1.0

Subnet Mask: 255.255.255.0

Maximum Number of users: 245

and now save it.

DHCP								
Interface	Fast	Ethernet0	▼ Serv	vice On	o Off			
Pool Name			ser	serverPool				
Default Gateway			192	192.168.1.1				
DNS Server				192.168.1.10				
Start IP Address : 192			58	1	0			
Subnet Mask: 255 255				255 0				
Maximum Number of Users : 245								
TFTP Server:			0.0	0.0.0.0				
WLC Address:				0.0.0.0				
Add	Add Sa				Remove			
Pool Name	Default Gateway	DNS Server	Start IP Address	Subnet Mask	Max User		WLC Address	
serverPool	192.16	192.16	192.16	255.25	245	0.0.0.0	0.0.0.0	

Now go to every PC and on their IP, configuration tabs, enable DHCP. Every PC should be able to obtain an IP address, default gateway and DNS server.

Static	
192.168.1.1	
255.255.255.0	
192.168.1.1	
192.168.1.10	
	[192.168.1.1 [255.255.255.0 [192.168.1.1

Result:

```
C:\>ping PC1

Pinging 192.168.1.3 with 32 bytes of data:


Reply from 192.168.1.3: bytes=32 time<1ms TTL=128
Reply from 192.168.1.3: bytes=32 time<1ms TTL=128
Reply from 192.168.1.3: bytes=32 time=1ms TTL=128
Reply from 192.168.1.3: bytes=32 time<1ms TTL=128

Ping statistics for 192.168.1.3:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 0ms, Maximum = 1ms, Average = 0ms

C:\>
```


Task 4


First add 3 PCs and 1 switch and 1 router and 3 servers




Now we will configure the servers first


DHCP server:







DNS server:





Web server:






Now configure the Router

```
Router>ena
Router>enable
Router#cof
Router#conf
Router#configure termi
Router#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#
Router(config)#interface GigabitEthernet0/0
Router(config-if)#
Router(config-if)#exit
Router(config)#interface GigabitEthernet0/1
Router(config-if)#
Router(config-if)#exit
Router(config)#interface GigabitEthernet0/0
Router(config-if)#interface GigabitEthernet0/0
Router(config-if)#ip add
Router(config-if)#ip address 192.168.2.1 255.255.255.0
Router(config-if)#no shut
Router(config-if)#no shutdown
Router(config-if)#ex
Router(config)#ip dhc
Router(config)#ip dhcp p
Router(config)#ip dhcp pool P1
Router(dhcp-config)#netwo
Router(dhcp-config)#network 192.168.2.0 255.255.255.0
Router(dhcp-config)#defa
Router(dhcp-config)#default-router 192.168.2.1
Router(dhcp-config)#dns
Router(dhcp-config)#dns-server 192.168.1.5
Router(dhcp-config)#ex
Router(config)#
```

Now go to every PC and on their IP, configuration tabs, enable DHCP. Every PC should be able to obtain an IP address, default gateway and DNS server.



Result:

